

# QUICKDRAIN™



Insert **QUICKDRAIN™** into the water. Position discharge hose so it lies below the bottom of tub being drained.



Pump **QUICKDRAIN™** up and down, with 15 long, fast strokes to establish water flow. To maximize flow, wait a minute, and then pump 5 to 10 more times. Maneuver **QUICKDRAIN™** to vacuum debris as it drains.



When water level is very low, angle tip of **QUICKDRAIN™** flush with tub or spa floor. Carefully maneuver and watch to ensure all the water is completely drained.