

## Deluxe Sunshade Attachment Instructions



- A. Hold the Deluxe by elastic area at the top of cover. Place elastic near the edge of the stroller canopy
- B. Find the triangular mesh window with ties on each side of the Deluxe – these keep the Deluxe in place on the stroller. Attach ties midway down on either side of the stroller frame.
- C. Securely attach the second set of ties near the handle bar of the stroller.
- D. Adjustable sun flap can be pulled backwards over stroller canopy for complete visibility or if baby is sleeping, covers the mesh completely for longer naps and full protection.

1. To transform the full coverage shade into a large sun canopy untie ties 'C'
2. Lift and pull elastic towards the rear of the stroller, placing elastic over the edge of the rear of the canopy. The center seam with mesh should align with the edge of the stroller canopy.
3. Pull 'C' ties around the back of stroller, tie the ties together to secure Deluxe into sun shelter position.
4. The sun canopy and sun flap can be adjusted to suit the position of the sun or your style preferences.

