

Model AA-1 Adjustable Armrest for Chair Models 105, 118-2, 241


Parts Listing




A
Washer
6 pcs.




B
30mm Hex Screw
6 pcs.



C
Model AA-1
Adjustable Armrest
2 pcs.



D
Wrench



CAUTION:

1. Do not put excess pressure on arms while getting up from, or sitting down in chair.
2. Check for loose screws and tighten them every 6 months.



Assembly Instructions

Tools Needed: Phillips Head Screwdriver

Please read all instructions before assembly.

- Step 1:** Turn Chair upside down and place chair on a clean, non-abrasive surface.
- Step 2:** Align the pre-drilled holes in the Model AA-1 Arms (**C**) with the holes in the bottom of the chair seat, making sure that the arms will be facing in the correct direction when chair is in the upright position.
- Step 3:** Place three Washers (**A**) onto three 30mm Hex Screws (**B**) and insert through Model AA-1 Armrest (**C**) holes and into chair seat.
- Step 4:** Tighten screws using supplied Wrench (**D**) or screwdriver. It is recommended that to assure screws are secure that a screwdriver is used to tighten screws.
- Step 5:** Repeat steps 2, 3 and 4 for other arm rest
- Step 7:** To adjust the height of the arms, press the Height Adjustment button located under the armrest, and pull or push arm up or down. Release button to lock into place.



Holly Springs, NC, USA
800-520-7471 (voice)
919-303-6389 (voice)
919-362-4765 (fax)
support@ofminc.com
www.ofminc.com