Any work done on the machine by opening the machine up or otherwise
will void the warranty unless authorization is given by Lobster, Inc.

201/202 - 110 volt Machine Can Interrior wiring diagram



Under no circumstances shall Lob-ster, Inc. be liable to the Customer or any other person for incidental or consequential damages of any nature, including, without limitation, damage for personal injury or damages to property.